

# Soil Water Reservoir


- Soil Texture
- Soil Structure
- Rootzone Depth
- Infiltrated Rainfall
  - Volume and seasonal distribution


# Soil Texture

Relative proportions  
of  
different particle sizes

*Sand - Silt - Clay*

# Soil Texture






- Excess or gravitational water
  - Available water, no plant stress
  - Available water, plant stress possible
  - Unavailable water
- } Available Water Capacity

# GOOD SOIL STRUCTURE

(GRANULAR)





# Rooting Depth Limitations

- Fine texture with poor internal drainage
- Dense, compact, or cemented subsoils
- Layered or stratified soil with abrupt change
  
- Rock
- Water table

# Rootstocks

- Shallow rooting nature
  - 5C, 5BB, 1103





Determine Depth Using:

Backhoe  
Auger


If wet in spring and  
Dry in fall --

# Rootzone Water Holding Capacity

- Water holding capacity X Rootzone Depth
- Ex. Clay Loam = 1.6 in/ft Available water
- Rootzone Depth = 5 ft
- $1.6 \times 5 = 8.0$  inches of available water

# Using Neutron Probe Data

Figure B-2. Winegrape non-irrigated in/ft by depth




# Measuring Water Sources


- Soil moisture
- In-season Rainfall
- Irrigation Water

# Soil Constituents by Volume

## At field capacity



# Soil Moisture Matrix



# Volume Units

- Rainfall inches/depth
- Crop Water Use inches/depth
- Soil moisture inches/depth

$\% = \text{in} / \text{in}$

$\% \times 12 \text{ inches} = \text{inches} / \text{foot soil}$

$\% \times \text{rootzone depth} = \text{inches water in rootzone}$


# Available Soil Moisture

- Moisture contained in the soil which vines can remove
- All available moisture is not equally available



# Available Soil Moisture

- Field Capacity – Perm wilt point
- Field Capacity
  - Upper limit when drainage ceases
- Permanent Wilting point
  - Lower limit when plants cannot extract moisture



- Excess or gravitational water
  - Available water, no plant stress
  - Available water, plant stress possible
  - Unavailable water
- } Available Water Capacity


# Soil Water Measures

- Soil Water Content
  - Quantitative
    - Percent water by weight or volume
- Soil Moisture Status or Tension
  - Qualitative
    - Centibars of Tension


# Moisture Status

- Tensiometers
- Gypsum Blocks


# Tensiometer



0 – 80 Centibars




# *Tension versus soil moisture content for two soil textures.*








# Gypsum Block








# Irrrometer Watermark Sensor/Meter





# Soil Water Content

## Direct / Indirect Methods

- Direct

- Soil sampling by volume

- Or--- by weight x soil bulk density

- Indirect

any method which relates a “reading” to soil sampling moisture content

# Indirect Methods

- Soil Dielectric

Time Domain Reflectometry (TDR)

Ground Penetrating Radar (GPR)

Frequency Domain Reflectometry (FDR  
or capacitance)

- Neutron Scatter

# Soil Dielectric

- The dielectric permittivity is a measure of the capacity of a non-conducting material to transmit electromagnetic waves or pulses.
- Dielectric Permittivity
  - Air = 1
  - soil minerals = 3 to 5  
(denser soils have higher apparent permittivities).
  - Water 81



# Influencing Factors

- Water Content
- Soil Temperature (small in most cases)
- Soil Porosity and Bulk Density
- Minerals (2:1 clays)
- Measurement Frequency
- Air Gaps (instalation– swelling soils)

# Frequency Domain/Capacitance

- A couple different methods are used however, they all use:
  - Electronic circuit in which the two plates, rods or rings use the soil between them as dielectric of a capacitor
- The change in the circuit output is related to the dielectric permittivity

Capacitance ( $C$ ), measured in Farads ( $F$ ), is defined as:

- the amount of charge ( $Q$ ) required to increase the voltage ( $V$ ) by one volt between two plates separated by a known distance containing an insulating material

Solar Panel

Cable

Data Logger

Ground Surface

Electrode

Electrode


Access Tube




Permanent logging  
Multi depth

Portable

Single point measure




## Capacitance Probe



# FDR

- Soil specific calibration curves are needed for soils that are highly conductive, have high organic content, or contain 2:1 clays


# Soil Specific Calibration




After Kim and Benson 2002




# FDR



# C-Probe




# C-Probe



C-Probe

12in 24 in 36 in 48 in 60 in Sum

Irr = 1.4 in




# ***FDR Advantages***

- Relatively inexpensive
  - low frequency standard circuitry
- No radiation hazard / hassles
- Fast response time
- Logging capable
- Portable

# *FDR Disadvantages*


- Small measurement volume sensitive to small-scale soil variations (most in 5cm)
- Sensitivity to installation
- Site specific calibration is necessary for accurate soil volumetric water content

# Neutron Scatter / Probe










# NP Field Calibration



# Calibration

- Down-hole samplers are pushed into the soil at the bottom of an augered hole to take fixed volumetric (60 cc) samples
- Device readings are taken at the same depths immediately after sampling
- Samples are oven dried
- Percent water content vs reading

# ***NP Advantages***

- Large measurement volume produces high precision
- Works well in stony soils and expansive clays
- Very accurate, when calibrated
- Air gaps and soil disturbance during access tube installation has minimal effects
- Multiple point measurements


# *NP Disadvantages*


- Costly
- Cannot be automated because radioactive source may not be left unattended
- Cost of regulation and licensing of a radioactive source/ and disposal cost
- Surface measurements inaccurate  $< 9$  in
- Heavy awkward device
- Time required for reading

# Available Soil Moisture

- Field Capacity – Perm wilt point
- Field Capacity
  - Upper limit when drainage ceases
- Permanent Wilting point
  - Lower limit when plants cannot extract moisture

water content ( $\text{m}^3 \text{m}^{-3}$ )








# Using Neutron Probe Data

Figure B-2. Winegrape non-irrigated in/ft by depth



# Soil and Water Holding / Supplying Variability

Variability within the vines root zone and on a field scale is the largest error when trying to approximate the mean soil moisture

## Soil Variability

Texture

Density

Root limiting conditions


Vine water extraction

# Solution to Variability

- More measurement points
  - Based on:
    - Level of confidence needed ie. 95%
    - Variability that exists
    - Mean Value expected

# Number of Sites

Mean = 6.59  
Sdev = 1.52



# Data Handling / Telemetry

- Wide range available
  - Direct hand held “pod” collection
  - Cell phone modem to data processing to internet acc



# Summary

- Volumetric Water Content
  - Dielectric Methods
  - Nuclear Methods
- All require field calibration if volumetric required
- Dielectric
  - Can be automated / unattended / transmitted
  - Generally inexpensive
  - Need a number of sites/depths to characterize the rootzone and field

# Looking Ahead

- Increased use of devices which can log transmit and allow automatic data processing. --- Dielectric methods
- The Neutron Probe is the standard and will be slow to replace by virtue of its advantages

# Sensor Area of Measure

- Most sensors read a small area
  - Tensiometers and Gypsum Blocks
    - Smallest area– a few cubic centimeters
  - Dielectric methods
    - Narrow disk shaped measurement area a few cm outside the well or from the waveguides
  - Neutron Probe
    - Largest area – a few inches in radius of the detector




# Precision Micro-irrigation



# Sensor Placement

- Depends on the goal of the measurement
- If measuring soil water depletion before irrigation--- not too important
- If measuring after irrigation– proximity to the emitter will effect the reading



# When To Measure Soil Moisture Quantitative( N Probe)

- Most valuable times:
  - Bud break
  - Just prior to 1<sup>st</sup> irrigation
  - Dry point

Bud break – Dry Point = Available water

Bud break – Prior to 1<sup>st</sup> irr = Water consumed

Prior to 1<sup>st</sup> irr – Dry Point = water remaining

# Measuring Effective In-Season Rainfall

$$\text{Effective Rainfall} = [\text{rainfall (in)} - 0.25 \text{ in}] \times 0.8$$

*Table C-3. Effective rainfall*

Day	Rainfall (inches)	Effective Rainfall (inches)
1	0.39	0.11
2	0.62	0.30
3	0	0
4	0	0
5	0	0
6	0	0
7	0.25	0
Weekly Total	1.26	0.41

# Measuring Water

## Volume Units

- Gallons
- Cubic feet

## Flow Rate

gpm

cfs

- Depth

- Inches

- Rainfall
    - Crop Water Use
    - Irrigation

in/hr

# Measuring Irrigation Water


- Flowmeters
- Emitter Discharge

# Totalizing Water Meter





# Proper Water Meter Installation



# Doppler Water Meter

Portable totalizing and instantaneous readings 2" to 9 ft dia.



pipe cross-sectional area X water velocity = Flow rate

# Discharge Method

Measure the flow rate at the discharge point

# Orchard / Vineyard Pots



Emitters

$\frac{1}{2}$  or 1 gph at nominal pressure



# Measuring Micro Irrigation Discharge Rate



# Micro system discharge rate

Volume of water collected (ml) in 30 sec X 0.0317  
= Discharge rate (gph)

# Average discharge rate to applied inches

## Ave. Discharge Rate

(gph) x no. discharge devices per plant /  
plant spacing (sq ft) x 1.6 = ave. application rate (in/hr)

$$0.5 \text{ gph} \times 2 \text{ emitter/plant} / 7 \times 10 \text{ ft} \times 1.6 = 0.02229 \text{ in /hr}$$

## Applied Water

in/hr x hrs of operation = applied inches

$$0.02229 \text{ in/hr} \times 24 \text{ hrs} = 0.52 \text{ in}$$



# Applied inches to Gallons per vine

- 0.52 inches X 27158 / vines/acre
- For a spacing of 7 x11 ft = 566 vines/acre
  
- $0.52 \times 27158 / 566 = 25$  gal/vine